



## PREMIUM TUBING CENTRALIZER

The Premium Tubing Centralizer is designed to be run in the tubing string to keep the tubing centralized which may help in preventing premature wear of the casing and tubing. The Tubing Centralizer also helps reduce the harmonics and vibrations caused by the PC Pump, potentially reducing premature wear on the tubing anchor and other downhole tools.

The Premium Tubing Centralizer can be installed directly above the pump for vibration and harmonics dampening effects and other units can be installed further up the tubing string to provide the tubing and casing protection.

The Premium Tubing Centralizer has full tubing ID specifications and is available for a large variety of casing sizes and tubing connections.

Casing Size		Maximum OD		Minimum ID		Connections*	
inch	mm	inch	mm	inch	mm	inch	mm
4 1/2"	114.3	3.625"	92.1	1.995"	50.7	2 3/8" EU	60.3
4 1/2"	114.3	3.625"	92.1	2.441"	62.0	2 7/8" EU	73.0
5 1/2"	139.7	4.250"	108.0	2.441"	62.0	2 7/8" EU	73.0
5 1/2"	139.7	4.250"	108.0	2.992"	76.0	3 1/2" EU	88.9
5 3/4"	146.1	4.500"	114.3	2.441"	62.0	2 7/8" EU	73.0
5 3/4"	146.1	4.500"	114.3	2.992"	76.0	3 1/2" EU	88.9
6 5/8"	168.3	5.250"	133.4	2.441"	62.0	2 7/8" EU	73.0
6 5/8"	168.3	5.250"	133.4	2.992"	76.0	3 1/2" EU	88.9
7"	177.8	5.500"	139.7	2.441"	62.0	2 7/8" EU	73.0
7"	177.8	5.500"	139.7	2.992"	76.0	3 1/2" EU	88.9

\*Alternative connections and specially engineered sizes are available upon request\*